



Gas



Liquid & Slurry



Solid & Powder



Steam & Water

SENTRY W7950 DEGASSING SPARGER

Single Line Conditioning Modules

SAMPLE CONDITIONING

The Sentry® W7950 sparger assembly is used to prepare a sample for taking a degassed cation conductivity measurement.

After the sample has been cooled and the pressure controlled, it enters the sparger assembly. It passes through a resin column to remove the ammoniated compounds and convert the neutral salts into their corresponding acids, enhancing the conductivity of these impurities.

The sample then passes through a sparging column in a down-flow direction. A regulated flow of technical grade nitrogen or helium gas is introduced into the bottom of the column and is diffused into the sample to create turbulence. As the sparging gas bubbles travel up through the column, they drive the volatile gases out of the sample, and both exit the column through the vent. The sample then is sent to a conductivity cell, where it can be measured free of these impurities.

MODELS

W7950

BENEFITS

The Sentry W7950 sparger assembly eases sample conditioning so samples can be measured free of impurities. The sparger assembly uses inert gas, and with no reboiler, there is no element to burn out and no hot spots to touch, and the sample never needs re-cooling. Samples pre-cooled to 77°F (25°C) remain at that temperature, ensuring the highest instrument accuracy.

FEATURES

- All sample-wetted parts are either 316SS or plastic
- Selection valve allows sample to be analyzed for either cation conductivity or degassed cation conductivity
- Versatile options include integral high purity conductivity analyzer; gas regulator; flow meter and flex hose; and isolation valve and flow meter



Sample. Monitor. Measure.

SENTRY

Any Application. Anywhere.

	W795	1	-	0	0	XX
BASIC MODEL	<input checked="" type="checkbox"/>					
INTEGRAL ANALYZER						
1 = No (Connection for remote analyzer)		<input checked="" type="checkbox"/>				
2 = Yes – See XX option						
				<input checked="" type="checkbox"/>		
SAMPLE INLET OPTIONS						
0 = None (Inlet bulkhead fitting only, for remote shutoff and/or flow control)						
1 = Inlet shutoff valve only				<input checked="" type="checkbox"/>		
2 = Inlet valved sample flow meter						
3 = Shutoff valve <i>and</i> valved flow meter						
SPARGING GAS OPTIONS						
0 = None						
1 = Flow meter mounted					<input checked="" type="checkbox"/>	
2 = Flow meter mounted, with flex hose (shipped loose)						
3 = Flow meter mounted, with gas cylinder regulator (shipped loose)						
4 = All of the above (flow meter, flex hose, regulator)						
NUMBERS FACTORY ASSIGNED based on analyzer, only used with W7952 model						<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
	W795		-			

SPECIFICATIONS	
dimensions	44 in. x 12 in. x 6 in. (1118 mm. x 305 mm. x 152 mm.)
weight	30 lb. (13.6 kg.)
materials	backplate: 304 stainless steel; tubing, valves: 316 stainless steel; flow meters: 316 stainless steel, acrylic
flow meters	sample: 20–240 ccm; inert gas: 0–1500 ccm
temperature gauge	0 to 200°F (-20 to 94°C)
connections	1/4 in. tube compression
sample conditions	pressure: regulate to 20 psig max (100 psig design) temperature: 125°F (51.7°C) max flow: 100–200 ccm optimal
sparging gas	flow: 600–800 sccm pressure: 20 psig type: nitrogen or helium (technical grade)

sentry-equip.com

966 Blue Ribbon Circle North, Oconomowoc, WI 53066 U.S.A. | +1-262-567-7256 | sales@sentry-equip.com

© 2018 Sentry Equipment Corp. All rights reserved. All product and company names are property of their respective owners. It is solely the responsibility of end users, through their own testing and analysis, to select products and materials suitable for their specific application requirements, ensure they are properly installed, safely applied and properly maintained, and to limit their use to their intended purpose. Improper selection, installation or use may result in personal injury or property damage.

S-SW-SPS-00015-4 11-20



COMPANY WITH
QUALITY SYSTEM
CERTIFIED BY DNV GL
= ISO 9001 =